

## Grandstream Wave App Setup for Android

Rev. 09.03.2019.RA The following instructions were created on an android 9.0 device.

## Requirements

Any user installing the Grandstream Wave application will need to receive an email containing a QR code to set up the application. To get this email, please see your site's technical contact or contact your voip system administrator.

1. Locate and install the Grandstream Wave App from your device's app store.



2. Grant the App permissions as you see fit. You must allow the phone to **Make and Manage Phone Calls** in order for the softphone to work.



3. After installation, it will display the softphone, or the empty account screen. If the account screen does not show, press the settings icon to access it.

3:57 📱 🗈 🗈 🛅 🔹	3:57 📱 🗖 🗖 🗖 🔹 🐻 LTE 🖌 🗎			3:58 🖬 🗖 🖬 🖡 🔞 🖓 🎯 🖓				
			<	Account Set	tings +			
<b>237</b> 04/ ℃ ♀ 237	/22 10:56 AM >	Account Setting		>				
Acts Office 04/	/22 10:55 AM >	Advanced Settings		>				
Net (561) 823		Provisioning Settings		>				
<b>Bill ap</b> (71 .016		Custom Settings	>					
Brand 100l (813) 29		About						
Mike .op								
Enter Phone Number	$\langle \times  $	Record		>				
+1 813- 26 <b>2</b> ABC	3 DEF	Debug		>				
4 GHI 5 JKL	6 MNO	Delete All Call History						
7 PORS 8 TUV	9 wxyz	Exit						
* 0 +	# 🖌							
Contacts Conf Keypad M	الله الله الله الله الله الله الله الل	Ontacts Conf	Keypad Me	ssages Settings	Q Contacts	Conf Keypad	Messages Settings	
< ●		•	$\bigcirc$			•		

4. Tap the plus sign in the corner to add an account. Choose **UCM Account (Scan QR Code).** Once the code is scanned, the account wll show as your extension number. A red dot means it is not ready, a green dot means it is good to go.

3:58 🖬 🖬 🖬	• В •	🐯 🖗 LTE 🖌 📋	4:04 🖬 🖬 📾 🔳	•	🐯 🍘 LTE 🖌 📋	4:07	b •	ଅତ 🛛 LTE 🖌 🔒	4:04	• b	2	🛱 🖗 LTE 🖌 🖥
<	Add New Account		<	Scan QR Code		<	Scan QR Code		<	Account	t Settings	+
GENERIC ACC			el prov Byzer Austin nablem i metti trom thin mensage in dia	played, click here to view it in a web browser		QR code cont	ains the following r	nodules:	104			
UCM Account	t ( Scan QR Code)	>		SIP Account Information You can use this settings to regis	1 ster to UCM server and log	Account Settin	IS					
UCM Account	t (Select QR Code Image)	>		General Settings Server Address 1: 10:50:50:2:506 Public IP Address: 67:76:7:98:50 Account Name Ryan Austin	50 60							
SIP Account		>		SIP User ID: 104 Authenticate ID: 104 Authenticate Password: 100	F							
	DERS		1000	User Settings User Portal Login URL-1: 10:50:5	02							
123Cloud				User Portal Login URI, for Public User Portal Login Name: 104 User Portal Login Password	67.78.7.98	Accour	t Settings					
1VOIP 4 ALL	& SWISS			Public IP Address, 67 78 7 98 500	50	Add New	Account 104					
42NETMedia				444		Ca	ncel	Done				
A1												
Abronix			4 b e =	Carry.	e O Grandstrajen Nersonia, Inc. ;							
Acestar Telec	coms Hong Kong Ltd.		33511 color C Settlat Production		250 - 9000 520 - 5456 Kart							
Antin			O Stanparty		USI - Advantation							
(Q) Contacts	Conf Keypad Messa	) 🌼 Iges Settings	The Right and		was 350 - Actual by was provided by Autor of the second by when a second by a		Continue Scanning			Conf Ke	ypad Message	es Settings
•	•		•	۲		•	•		le le	•		

If you have a red dot for a long period of time, there is a network issue preventing your phone from reaching the system. Turn off Wifi and use mobile data if this happens. Most red dot issues occur on wifi networks.