

Grandstream Feature Codes

Rev. 03.13.2018

Voicemail and Phone Features

Personal Voicemail Access: *97

Group Voicemail Access: *98

Send call directly to voicemail: Press transfer, then * + extension

Paging: *81 + extension

Intercom: *80 + extension

Pick up Ringing Group Call: **

Pick up Ringing Extension: *8 + extension

DND (Do Not Disturb) and Call Forwarding

DND (Do Not Disturb):

Activate: *77 Deactivate: *78

Call Forward Busy:

Activate: *90 Deactivate: *91

Call Forward No Answer:

Activate: *92 Deactivate: *93

Call Forward Unconditional: Activate: *72 Deactivate: *73